

## CO2/HP AIR TANK WARNING



- VALVES MUST BE INSTALLED OR REMOVED ONLY BY QUALIFIED PERSONNEL.
- BOTTLE MUST BE RETESTED SEE CO2/HP TANK LABEL FOR RETEST DATE!
- Improper use, filling, storage or disposal of this cylinder may result in death, personal injury and property damage.
- This cylinder must be filled only by properly Trained personnel in accordance with CGA Pamphlets P.1 and G-6.3 available from the Compressed Gas Association WWW.CGANET.COM
- Do not over pressurize. Do not expose pressurized cylinder to temperatures in excess of 130 degrees F.
- Do not expose cylinder to corrosive materials and do not clean with caustic cleaners.
- Do not alter this cylinder in any way.
- Cylinders heated to a temperature of 250 degrees F or more must be condemned or requalified in accordance with test defined in CFR-49.
- Keep cylinder out of reach of children.
- The valve should NEVER be detached from the canister. Should this occur, please seek assistance from a trained airsmith immediately.
- This tank is intended for paintball use only.

## SPYDER TL-X

### ITEM # Name of Parts

|       |                               |
|-------|-------------------------------|
| 01    | Spyder Barrel Plug            |
| 1002F | 12" Barrel (Silver)           |
| 04GA  | Ball Stopper w/Detent Cover   |
| 05B   | M4 x 6 Screw (Silver)         |
| 28041 | Direct Feed (Silver)          |
| 28061 | Receiver (Blue)               |
| 28081 | Vertical Adapter (Blue)       |
| 28082 | Low Pressure Chamber (Silver) |
| 07    | M5 x 14 Screw w/ Washer       |
| 09    | O-Ring #015 80D               |
| 10A   | Valve Spring                  |
| 11    | Cup Seal Guide                |
| 12    | Cup Seal                      |
| 13    | Valve Pin                     |

### ITEM # Name of Parts

|       |                       |
|-------|-----------------------|
| 14    | Valve Body            |
| 15    | Valve Body Screw      |
| 16    | M5 x 12 Screw (Black) |
| RF17  | Venturi Bolt          |
| 1717A | Retaining Screw       |
| 1717B | Retaining Spring      |
| 1717C | Retaining Bearing     |
| 18B   | Striker Bolt (#19A)   |
| 19A   | Striker O-Ring        |
| 20    | Barrel O-Ring (Black) |
| 21    | Bolt Pin              |
| 22    | M4 X 8 Screw (Black)  |
| 23B   | Quick Disconnect Pin  |
| 23C   | Disconnect Pin Lock   |

### ITEM # Name of Parts

|       |                                |
|-------|--------------------------------|
| 23FA  | Striker Bolt Plug (Silver)     |
| 25    | Striker Spring                 |
| 26A   | Striker Buffer                 |
| 27    | Striker Spring Guide           |
| 27A   | Flat Disc                      |
| 29B   | Lock Screw                     |
| 28291 | Thumb Adjuster w/ screw (Blue) |

### ITEM # Name of Parts

|       |                              |
|-------|------------------------------|
| 31B   | Trigger Sear                 |
| 28311 | Deluxe Trigger Frame         |
| 32E   | 45 Grip Cover                |
| 33C   | Grip Cover Screws (M3 x 10)  |
| 33F   | Nut Screw                    |
| 2835  | C/A Adapter (Blue)           |
| 28351 | Deluxe Drop Forward (Silver) |

### ITEM # Name of Parts

|       |                               |
|-------|-------------------------------|
| 36D   | 5/32" x 5/8" Screw            |
| 36E   | 5/32" x 7/8" Screw (Black)    |
| 37A   | Filter O-Ring                 |
| 37B   | Air Filter                    |
| 37C   | Disconnect O-Ring #011(Black) |
| 37D   | Plastic Washer                |
| 37J   | Disconnect Hose               |
| 2841  | Spare Parts Kit               |
| 28441 | Gas Thru Fore Grip (Silver)   |
| 28442 | Mini Fore Grip (Blue)         |
| 38A   | Safety Button Set (Medium)    |
| RF39  | Cocking Knob (Blue)           |
| 42F   | Male to Male Metric Adapter   |
| 48    | Trigger Roll Pin              |
| 49    | Sear Roll Pin                 |
| 49A   | Secondary Sear Roll Pin       |
| 5814  | Double Trigger                |

